


TRONITEC SERVICE DOCUMENT (TSD#26) MODEL 900: LUBRICATION REMINDER

Rev. 9.9.08

DO NOT REMOVE THE OIL AND GREASE THAT IS PRESENT ON THE CARRIAGE GUIDE SHAFT AND THE LEADSCREW PRINTER ASSEMBLY!

Removing the oil and grease will cause the printhead carriage to bind and lockup. If the carriage guide shaft becomes dry after prolonged use, 3-IN-ONE oil or a similar product should be applied. **DO NOT USE SPRAY LUBRICANTS.**

Reference the diagram below for part locations.



Tronitec, Inc. repairs, refurbishes, and resells equipment made by the original equipment manufacturers. Tronitec, Inc. is not associated with, affiliated with, related to, authorized by, nor certified by referenced companies. Manufacturers names, product names and part numbers are for reference and identification purposes only. All product names and company logos are the trademarks of their respective owners.