## 417074/416828 NOTE (TSD#3)

Please be sure the battery jumper is in the "ON" position or this controller board may not power up.

Tronitec, Inc. repairs, refurbishes, and resells equipment made by the original equipment manufacturers. Tronitec, Inc. is not associated with, affiliated with, related to, authorized by, nor certified by referenced companies. Manufacturers names, product names and part numbers are for reference and identification purposes only. All product names and company logos are the trademarks of their respective owners.