TRONITEC SERVICE DOCUMENT # 57

Verifone Thermal Receipt Printer Guide
Part # P040-02-040 RP-300 / RP-310

- <u>To Perform a Printer Self Test for the RP-300 / RP-310 Printer</u> :

  1. Power ON the printer while simultaneously holding the Print Feed Button.

- <u>To Set the Baud Rate for the RP-300 / RP-310 Printer</u> :

  1. The Baud Rate on the RP-300 / RP-310 Printer is Set with Dip Switches # 7 and # 8 on Row 1.

  2. For 38,400 Baud Set Switches # 7 and # 8 on Row 1 to the OFF position.

  3. For 9600 Baud Set Switch # 7 Row 1 to OFF and Switch # 8 Row 1 to ON.

- <u>RP-300 / RP-310 Printer DIP Switch Bank Access</u> :

  1. Power OFF the printer and disconnect from power and communication source.

  2. Remove the DIP Switch Access Panel fastening screws on the front bottom of the Printer.

- <u>Baud Rate settings by Application for the RP-300 / RP-310 Printer</u> :

  1. 38,400 Baud is the common setting for the Verifone Commander system.

  2. 9600 Baud is the common setting for the Verifone Sapphire Ruby system.

TRONITEC SERVICE DOCUMENT # 57

● <u>Accessories for the RP-300 / RP-310 Printer</u> :

1. RP-310 Receipt Printer Paper :
   See <u>Item Code 7137.</u>

2. RP-310 Receipt Printer External Power Supply :
   See <u>Item Code 2343 </u>.

3. 6 Foot RP-310 Printer Power Cable to Verifone Topaz, Ruby2, RubyCI.:
   See <u>Item Code 7222</u>.

4. All in one 10 Foot RP-310 Printer Communication Cable :
   See <u>Item Code 8770</u>.

5. Alternative 10 Foot Communication Cable Assy. :
   See <u>Item Code 6899 and 6902</u> .

TRONITEC